



FOLD AND UNFOLD - QUICK REFERENCE GUIDE

A18-60'/66' and A26-60'/66'

Refer to Operators Manual for complete instructions

UNFOLDING THE TOOLBAR FROM TRANSPORT TO FIELD POSITION

1. RAISE CENTER SECTION AND INNER WINGS AND VISUALLY VERIFY THE TOOLBAR IS FULLY RAISED
2. PUSH SCV II FORWARD TO DETENT IN CONTINUOUS MODE
3. DISENGAGE TRANSPORT LATCHES BY HOLDING LATCHES SWITCH IN TRANSPORT POSITION UNTIL COMPLETELY DISENGAGED
4. UNFOLD TOOLBAR BY HOLDING MAIN WINGS SWITCH IN FIELD POSITION UNTIL WINGS ARE UNFOLDED. WINGS WILL BE IN LINE WITH CENTER SECTION WHEN FULLY UNFOLDED
5. ENGAGE MAIN WING LATCHES BY HOLDING LATCHES SWITCH IN FIELD POSITION UNTIL WING LATCHES ARE FULLY ENGAGED
6. HOLD FLIP WINGS SWITCH IN FIELD POSITION TO UNFOLD THE FLIP WINGS
7. DISENGAGE SCV II AND REMOVE TRANSPORT CYLINDER LOCKS FROM MAIN LIFT CYLINDERS

FOLDING THE TOOLBAR FROM FIELD TO TRANSPORT POSITION

1. RAISE CENTER SECTION AND INNER WINGS AND VISUALLY VERIFY THE TOOLBAR IS FULLY RAISED
2. PUSH SCV II FORWARD TO DETENT IN CONTINUOUS MODE
3. HOLD FLIP WINGS SWITCH IN TRANSPORT POSITION TO FOLD THE FLIP WINGS
4. DISENGAGE WING LATCHES BY HOLDING LATCHES SWITCH IN TRANSPORT POSITION UNTIL COMPLETELY DISENGAGED
5. FOLD TOOLBAR BY HOLDING MAIN WINGS SWITCH IN TRANSPORT POSITION UNTIL MAIN WINGS ARE SEATED IN TRANSPORT RESTS AT THE REAR OF THE MACHINE
6. ENGAGE TRANSPORT LATCHES BY HOLDING LATCHES SWITCH IN FIELD POSITION UNTIL THEY FULLY ENGAGE INNER WINGS
7. DISENGAGE SCV II AND INSTALL TRANSPORT CYLINDER LOCKS ON BOTH MAIN LIFT CYLINDERS